#### Hands-On

# Tellabs 1000 (UMC1000) LIVE Virtual System Maintenance & Troubleshooting



# **Course Description**

The Tellabs 1000 (UMC1000) Maintenance and Troubleshooting Course (formerly the AFC UMC1000) is designed to provide any student with a solid understanding of the various aspects of the AccessMAX/MSAP-series platform and its many features and options. The roles of a 1000 network shelf within a modern switching & transport network is explored, with discussions on its theory, options, maintenance, provisioning, and troubleshooting.

The hardware design of the system and its versions (POTS, ATM, ADSL/VDSL, PON) are explained, along with optional LET/RST and TR-8, TR-57, & GR-303 configurations, including connections to existing Class 5 switching systems. Various options are explained, including the different types of



customer POTS plug-ins, T1, DS3, and ADSL/VDSL. Key concepts like TDM switching, copper and optical transport, and host-remote are explained, plus newer services like FTTP and OLT/ONTs are introduced. Transaction Language 1 (TL1), Craft Interface GUI, Panorama, and other input-output options are shown. Common maintenance functions like checking alarms, air filters, and backups are discussed, along with more advanced troubleshooting procedures for card-level repair, and for analysis of host T1 links with EOC/TMC channels. Other AccessMAX equipment is also reviewed, including DMAX, EMAX, as well as UMC variants within the Multiservice Access Platform (MSAP) series, including the multiple types of RSC cabinets. Fundamentals of telecom copper and fiber networks is also provided, to help the student understand the many ways of connecting to the equipment, and to understand its many features.

Symptom investigation and troubleshooting are demonstrated using previous trouble examples, and through actual troubles which may exist in the network. Common fault types and best practices are also presented, to help prevent troubles from occurring in the first place. In addition to supporting independent problem-solving skills, the course helps provide an excellent background for NOC and TAC interaction.

Our non-intrusive exercises equip the student to conduct day-to-day maintenance activities and show how to perform troubleshooting procedures, including aspects of problem isolation, cabling and port/card provisioning, which helps prepare students for higher-tier support interaction. The course is flexible, allowing the most important content for a particular group of students to be emphasized, and to allow for emphasis on the particular MSAP/UMC1000 platform(s) in use.

**Students Will Learn** 

- Switching Fundamentals including ATM & SONET
- TDM-to-GR-303 Interfaces
- MSAP/UMC1000 Theory of Operation
- Plug-in Types & Differences
- System Access via CUI, LAN or Panorama
- How to use commands in Craft Interface and TL1
- Use and understand AFC & Tellabs documentation
- Basic provisioning of cards and transceiver ports
- How to find the physical location of a fault
- How to change cards
- How to backup configuration files & restore the system
- Troubleshooting by previous examples
- And much more...

# **Target Audience**

Technical staff such as Central Office Technicians, combo-techs, and those responsible for the maintenance and troubleshooting of switching systems, plus NOC/SCC personnel who must respond to alarms. No previous background is required, although some familiarity with CO or switching equipment would be beneficial. Management and provisioning personnel will also benefit, providing a greater understanding of the resources needed for the system, and how to support it.

# **Prerequisites**

A basic understanding of telecommunications and networking principles is helpful due to the accelerated nature of the course. Any of our BTS switching courses such as TDM Switching Fundamentals Course are available for students with little or no previous telecom background.

# **Course Outline**

Module 1: Switching Fundamentals

- Optical Safety
  - Laser Power Levels & Class System Visible & Non-Visible Wavelengths
- T&R, E&M, 2/4/8 Wire Circuits, Battery
- Electrical vs. Optical Power
- Decibels
  - logarithmic scale

copper & optical measurements

Digital: A/D & D/A Conversion

Time Division Multiplexing (TDM)

Pulse Code Modulation (PCM)

- Frequency Division Multiplexing (FDM)
- Time Division Multiplexing (TDM)

#### - Carriers & Protocols

Triple-Play Services

Line Coding & Transmission Protocols

DS0, DS1, DS3

OC-x, STS, STM

AE, GPON

SIP, VoIP

Telcordia GR-303, GR-57, GR-08

- Carrier Signal Comparison
- Interconnections

UTP, Coax, Fiber

MMF, SMF

Connectors (SC, LC, etc.) & Transceivers (SFP, QFP, etc.)

- IP Networking Overview

OSI Model

TCP/IP

LAN, VLAN

Servers: DHCP, DNS, NTP, FTP, TFTP

- A Converged PSTN

### Module 2: UMC1000 Theory of Operation

- TDM Switching Theory

Host-Remote, COT/RT

**GR-303 Remotes** 

**EOC & TMC Links** 

POTS, ADSL/VDSL, FTTP

- UMC1000-series Platforms

Standard POTS LET w/RST Options

**ATM Circuits** 

ADSL, VDSL Services

Fiber Optic Interfaces (PON OLT/ONT)

- Hardware Modules:

Processors: CPU-2, CPU-3, DLP

Transceivers: T1, T1-HDSL, T1 Async, OC-3, OC-12

Shelf: EBC, PSU, Fans, Rectifiers Access: IPMI, CPU, GbE22x

Service: L-POTS, R-POTS, UVG, IP-POTS, HD R-POTS, ADSL, PON

Timing: ETI, BITS, T1 Derived

- System Features
- End-to-End Network Call

#### Module 3: System Access

- I/O Ports

CPU, GbE

IP Access (IPMI)

- Access Methods

Craft User Interface (CUI)

Panorama Element Management System

TL1 CLI

- CUI Commands

Login, Logout, Version

**Equipment Inventory** 

Status & Trouble

- Panorama Commands

Login, Logout, User Accounts

Initial Views, Menu Options

- FTP, SFTP, TFTP

File transfer & authentication servers

Software loads & AUP

#### Module 4: Commands

- OS & Command Structure
- Craft User Interface Menu

Navigation Menu, Capabilities

Provisioning

Maintenance

Testing

Traffic

Administration

All Current Alarms

Help, Shortcut Keys

- Sample CLI Commands

Login, Alarms, Status, Provisioning, etc.

- TL1 Commands

TL1 Reference

login, alarms, status, provisioning, backup, etc.

- Panorama INM (EMS/NMS)

Sample GUI commands

#### Module 5: Documentation

- Document Types, Numbering & Revisions

MSAP/UMC1000 Documents

0600 Series (AFC)

76 Series (Tellabs)

Ordering Guides

Installation Guides - general, shelf-specific

Product Data Sheets & Application Notes

FSBs/CUS Docs

Third-Party Documents (SFP, cables, host switch)

- Tellabs Website

#### Module 6: Administration & Maintenance

- System Back-up

AUP Program, Panorama

- System Status

LED Status, GUI

Status & Alarms (List Current, History)

- Drop Testing

**OSP** Measurements

- Loopbacks

System Loops, Hard Loops

- Plug-in Replacement

Part Numbering root, suffix

CLEI/HECI

Module Replacement Procedures (Maintenance & Testing docs)

Power, POTS examples

- Configuration & Provisioning

Plug-in discovery

Configuration - POTS card, XCVRs

Configuration - shelf attributes

- System Backup

Database Save, Restore (Panorama GUI, CUI)

- Software Upgrades

Automatic Upgrade Program

System vs. Plug-in Upgrade

#### Module 7: Troubleshooting

- NOC/SCC Interaction, ESD Precautions
- Tools & Resources

**Troubleshooting Documents** 

Tools: TDR/OTDR, Power Meters

- Alarms & Faults

Alarm Information (GUI, CLI) & LEDs

Alarm Mappings: Plug-in Fails, Config Mismatch, Database, Errors, Power, etc.

SFP & Cabling - reflections, bend radius, abrasion

- Troubleshooting:

Alarm Clearing

Traffic Monitoring

Plug-in change

- System Logs
- Fault Clearing Strategy

Alarm Symptoms

Locating Procedures: CO or Customer side, LET or RST

EOC, TMC link errors

- Troubleshooting Examples

CPU Restart & Recovery

Bad transceiver

Provisioning/Activation Issues

Student Examples

#### Module 8: Translations Introduction

- Modifying the Database

Listing & Modifying

- Cross-Connects

TR-57 COT/RT

GR-303 Groups, DLP & T1 Spans

CRVs

- Transceiver Settings

T1, FO, OC-3, OC-12

# **Notes**

The course runs in a 5 day format, but can be combined or integrated with other topics like TDM Switching courses for a full end-to-end training program.

The course is designed to run in ether a Live Instructor-Led Virtual Classroom or In-Person Classroom setting. Virtual Field Trips can be added to allow students an opportunity to see and understand where all the parts of the system are found, what they do, and provide a better end-to-end understanding of the system.

# **Delivery Method**

LIVE Virtual Instructor-led with a flexible approach that adjusts content most relevant to students. Includes various non-intrusive labs, demonstrations, and exercises to help students focus on and retain the material presented.

# **Equipment Requirements**

(This apply's to our hands-on courses only)

Students must have Virtual and/or remote-access to an MSAP/UMC1000 system for this training.

BTS always provides equipment to have a very successful Hands-On course. BTS also encourages all attendees to bring their own equipment to the course. This will provide attendees the opportunity to incorporate their own gear into the labs and gain valuable training using their specific equipment.

# **Course Length**

5 Days